

Fluid Management 209 North Main Street Bryan, Ohio 43506 USA Tel +1 (800) 495-0276 arotechsupport@irco.com www.arozone.com

Premair Miniature 3-Way and 4-Way Valves Port Identification

The Premair Miniature 3-way and 4-way valve labels include a symbol that depicts airflow within the valve. However the symbol on the label does not match how the ports are identified on the valves.

2-Position, 3-Way Valve Label	 This represents the air-flow symbol on the label for a 2-position 3-way valve. It identifies the ports as: "IN," for the air input "OUT" for the valve's output "EXH" for exhaust. However, on the valve body, the ports are identified in a different manner. Here is the correct identification of each port and it's function: Port #1 = Inlet if plumbed Normally Closed (Exhaust if plumbed normally open) Port #2 = Output Port #3 = Exhaust if Normally Closed (Inlet when plumbed normally open)
2-Position, 4-Way Valve Label	 This represents the air-flow symbol on the label for a 2-position 4-way valve. It identifies the ports as: "IN," for the air input "1" for the valve's primary output "2" as the valve's secondary output "EXH" for exhaust. However, on the valve body, the ports are identified in a different manner. Here is the correct identification of each port and it's function: Port #1 = Inlet Port #2 = Primary Output Port #3 = Exhaust

